

Chameleon Chair® Collection

•PALMER SNYDER•

Chameleon Chair Collection®
Fanfare Chair
Cleaning Instructions
for
White Cushions



Before You Begin....

Please Read this Entire Set of Instructions

Contact Us Immediately if you have any Questions: (310) 787-9200 (PST)

You Will Need:

1. A Container of Warm Clear Water
2. Two (2) Clean Empty Spray Bottles
3. Soilove Stain Remover
4. Bleach
5. Gloves
6. Stack of Clean, Dry WHITE Towels
7. Cushions to be Cleaned
8. Drying Racks
9. Industrial Fan (optional)



Prepare: Apply Gloves and Fill the Spray Bottles

- 1) Fill one spray bottle with Soilove. Do not dilute the Soilove with water.
- 2) In the other spray bottle, fill with a mixture of half bleach, half water (a 1:1 mixture).

Caution! Clearly label each spray bottle. Wear gloves throughout the entire cleaning process.

Step 1: Spray Soiled Areas Directly with Soilove



Step 2: Dampen a towel in clean warm water. Wring the towel so that it is damp but not dripping.



Step 3: Wipe soiled areas with the damp towel, lifting off the stains.



Step 3 (continued): As you remove food stains, continuously fold the towel. Wipe with a clean area of the towel as often as possible.



Step 3 (continued): If the towel gets too dirty, replace with a clean damp towel.




Step 4: Check for additional stains. If stubborn stains remain, you may use a small amount of bleach. Spray a small amount of the bleach and water mixture onto a damp white towel.

Caution! NEVER APPLY BLEACH DIRECTLY TO CUSHIONS.



Step 4 (Continued): Apply the bleach treated towel to the stains.

For stubborn ink stains, treat a damp towel with 90% Isopropyl Alcohol.



Step 5: After stains are removed, wipe the entire cushion, including the sides of the cushion, with another fresh clean dampened towel.

This step prevents water marks from appearing on the cushion.




Step 6: Use a clean DRY white towel to blot and wipe the entire cushion. Blot thoroughly to remove excess moisture.



Step 7: Place cushions on a clean metal drying rack. Allow air flow around all sides of each cushion.

Cushions must dry **THROUGHLY** to avoid foam damage, odor or mold. Drying time typically requires 48 hours, or longer for humid environments.



Step 7 (Continued): The use of an industrial fan is recommended in humid climates.

